
Section 2

Feature Number Lists

โพรเฟสชั่นแนล พี. เอ. บี. เอ็กซ์.

30/270 ซอยนวมินทร์ 80 แขวงนวลจันทร์ เขตบึงกุ่ม กรุงเทพฯ 10230

Hotline : 084-920-5065 Tel : 02-519-1718 , 02-107-3057

E.Mail : info@pfpbx.com , jirasak_service@hotmail.com

www.pfpbx.com

2.1 Feature Number Lists

2.1.1 Feature Number Lists for User

Description

It is possible to change extension settings by dialing from an extension. In addition, dialing feature numbers allows you to use those features.

Operation

Dial the following feature numbers from an extension. Feature numbers are specified in 2.2.4 PBX Configuration—[1-4] System—Numbering Plan in the Programming Item List.

[Programming by dial]

Function Name	Feature Number (Default)	Parameter	References
Walking COS	*47	[Extension Number] [Extension PIN ¹] [Idle Line Access Number] [Destination phone number]	3.4.1 Toll Restriction (TRS) 3.4.2 Walking COS (TRS level)
Account Code		[*] [Account Code] [Idle Line Access Number] [Destination phone number]	3.4.1 Toll Restriction (TRS) 3.4.3 Account Code Entry
Extension Dial Lock Set / Cancel	*77	[0: Cancel] [Extension PIN ¹] [#] [1: Set]	3.4.5 Extension Dial Lock
FWD/DND Set / Cancel	*710	[0: FWD/DND OFF] [1: DND ON] [2: FWD ALL ON] [Forwarding destination phone number] [3: FWD BUSY ON] [Forwarding destination phone number] [4: FWD NA ON] [Forwarding destination phone number] [5: FWD Busy/NA ON] [Forwarding destination phone number]	3.1.9 Call Forwarding (FWD)
Extension PIN Set / Cancel	*799	[0: Cancel] [Extension PIN ¹] [#] [1: Set] [New Extension PIN ¹] [#] [New Extension PIN ¹] [#]	3.4.2 Walking COS (TRS level) 3.4.3 Account Code Entry 3.4.5 Extension Dial Lock

¹ The extension PIN is specified in 2.3.2 PBX Configuration—[2-2] Extension—Phone—PIN in the Programming Item List.

PIL Reference
2.3.1 PBX Configuration—[2-1] Extension—Port
2.3.2 PBX Configuration—[2-2] Extension—Phone
2.2.4 PBX Configuration—[1-4] System—Numbering Plan

[Feature List]

Function Name	Feature Number (Default)	Parameter	References
Trunk Line / Trunk Group	8	[#] [Trunk line Group Number] [Destination phone number]	3.2.3 Line Access, Trunk Line Group
	8	[0] [Single Trunk line Number] [Destination phone number]	3.2.4 Line Access, Trunk Line
Idle Line Access (Local Access) - 1	9	[Destination phone number]	3.2.2 Line Access, Automatic
Idle Line Access (Local Access) - 2	0		
Feature	* (Fixed)	[Feature Number]	
Redial	#	None	3.2.7 Redial
System Speed Dialing	**	[0][0][0]-[1][9][9]	3.3.1 System Speed Dial
Paging	*33	[Group Number (2 digits)]	3.10.1 Paging
Group Call Pickup (Specified Extension Group)	*40	[Group Number (2 digits)]	3.1.8 Call Pickup
Group Call Pickup (Own Extension Group)	*40	[#]	3.1.8 Call Pickup
Directed Call Pickup	*41	[Extension number] [Extension number (2 digits)] [#]	3.1.8 Call Pickup
Call Park ¹	7	[0][0]	3.7.2 Call Park
Call Park Retrieve	7	[0][1]-[2][4]: Park Area Number	3.7.2 Call Park
Door Open	5 (Fixed)	None * This feature can only be used when talking to the doorphone.	3.11.2 Door Open

¹ Before the operation, put the current call on Consultation Hold. (Refer to 3.9.1 Three-party Conference)

PIL Reference
2.3.1 PBX Configuration—[2-1] Extension—Port
2.3.2 PBX Configuration—[2-2] Extension—Phone
2.2.4 PBX Configuration—[1-4] System—Numbering Plan
2.3.5 PBX Configuration—[2-5] Extension—Doorphone

2.1.2 Programming by Dial for Manager

Description

It is possible to change the settings of the PBX system or view them from an extension assigned as a Manager. In addition, dialing feature numbers allows you to use those features.

Operation

Dial the following feature numbers from the Manager extension. Feature numbers are specified in 2.2.4 PBX Configuration—[1-4] System—Numbering Plan in the Programming Item List.

When dialing is complete and the settings are changed, the call will be disconnected after the confirmation tone is heard.

[Programming by dial]

Function Name	Feature Number (Default)	Parameter	References
OGM Record / Clear / Playback	*36	[0: Clear] [DISA floating extension number]	3.12.4 Outgoing Message (OGM)
		[1: Record] [DISA floating extension number]	
		[2: Playback] [DISA floating extension number]	
Time Service (Day / Lunch / Night) Switch	*780	[0: Day]	3.12.1 Time Service
		[1: Night]	
		[2: Lunch]	
		[#: Confirm the current Time Service]	
Door Open	*55	[Doorphone Port No.]	3.11.2 Door Open
System Setting	*#	Trunk Attribution [System PIN ^{*1}] [#] [400] [#] [Trunk line number] [#] [N] [#] Note [N] = [0]: No Connect [N] = [1]: Analog	Programming Item List 2.4.1 PBX Configuration—[3-1] Trunk—Port—Main—Attribution
		Trunk Dialing Mode [System PIN ^{*1}] [#] [410] [#] [Trunk line number] [#] [N] [#] Note [N] = [0]: DTMF [N] = [1]: Pulse	Programming Item List 2.4.1 PBX Configuration—[3-1] Trunk—Port—Analog - Basic—Dialing Mode
		HTTPS Port [System PIN ^{*1}] [#] [196] [#] [N] [#] Note [N] = [0]: Close [N] = [1]: Open	Programming Item List 4.2.1 Maintenance—[1-1] Management—Web Programming—Web Programming-Web Programming-HTTPS Enable

^{*1} The System PIN is specified in 4.2.1 Maintenance—[1-1] Management—Web Programming—System PIN for Manager in the Programming Item List.

PIL Reference
2.2.4 PBX Configuration—[1-4] System—Numbering Plan